

DIY Measuring a Corner Window

Thanks for choosing Urban Curtains + Blinds for your new blinds. To help you out we have created this easy to follow measure guide.



Determine which blind is the “through blind” as shown in the diagram below. We generally recommend that the through blind is the main window facing you whilst using the room or where you achieve the most privacy to stop vision down the gap between the butting blind.

1. Take the width measurement of the Blind 1 (run through blind).
2. Take the width measurement of the Blind 2 (butt blind).
3. Apply deduction to the Blind 2 (butt blind), this is approx. 70mm for most blinds, however if the drop is over 2000mm, you may need 75mm. The deduction of the butt blind allows the track to butt up to the through track.
4. Measure the drop of each blind in 3 places and take your smallest measurement.



Thanks,
From the Team at
Urban Curtains + Blinds